

Key names:



END key:

Repeatedly pressing the End key returns you to the beginning.

Redial:

The last number dialed is dialed again.
Press the Redial key.

Foxkey:

Trust the Foxkey. It always performs the right function for every situation!
The most important functions are explained below.

Light-emitting diode (LED):

LED is lit when not calling: Callback or message from other callers are present.
1. Pick up the handset.
2. Press the Foxkey.
3. You are connected to the caller in callback mode or with your mailbox.

**Connecting/
Transferring:**

During a call:
1. Press the Foxkey.
2. Enter the number and wait until the call is answered.
3. Put the handset on-hook and the call is transferred (if nobody picks up, press the End key to reconnect the first call).

Brokering:

Switching between two callers and simultaneously conducting two calls.
During a call:
1. Press the Foxkey.
2. Enter the number and wait until the call is answered.
3. Press the Foxkey again to switch callers.

Conference call: You can connect several callers for a conference call.

During a call:

1. Press the Foxkey.
2. Enter the number and wait until the call is answered.
3. Press and hold the Foxkey to activate conferencing.
4. Leaving a conference call: Put the handset on-hook.

Callback: Request callback: The person is busy or does not answer.

1. Press the Foxkey.
2. Put the handset on-hook.
3. Delete callback, press the Foxkey.

The telephone does not function as desired: Pick-up the handset, and press the Star key once and 0 twice to reset all active functions.

Further functions and settings of the telephone as well as the declaration of conformity are available in the extensive User's Guide. It is available from your system administrator or you can access it at:

<https://pbxweb.aastra.com>